

MANUAL FOR INSTALLATION AND USE OF THE CAMSC APP FOR WIFI AUDIO RECORDERS

IMPORTANT (2026): Due to regulatory restrictions, live listening has been removed from the latest version of the CamSC app. Devices running an older app version keep full functionality, including live listening. If you update to the latest CamSC version on iOS, live listening is no longer available and a previous app version cannot be installed on iPhone. If you update on Android, you can install the previous app version to keep live listening. All other functions (recording, voice activation, SD card access, remote download and playback, settings) work in every app version.




DOWNLOAD AND INSTALLATION:

Scan QR code with your mobile, choose Apple store or Google Play store link and download CamSC app on your mobile and install it.

Note: The version available in the store is the latest version, which does not include live listening.

Android: The previous CamSC Pro version with live listening is available [here](#). Do not update the app from Google Play afterwards.




CREATING ACCOUNT AND ACTIVATION:

- Select European countries if you are from Europe
- Select the REGISTRATION tab.
- Enter your email and choose a password (8charactersmin.)
- Check the service agreement box and press SEND CAPTCHA.
- Check your email to receive the CAPTCHA code
- Enter the CAPTCHA CODE and tap REGISTRATION




ADDING DEVICE AND CONNECTING TO YOUR WIFI

- Turn on your device and turn on PAIRING MODE.
- Connect your mobile to local Wi-Fi. Enable Bluetooth on it.
- In the CamSC app, tap +, then Audio Recorder, then CAM-3BDXXX. Choose your local wifi name and password, then tap NEXT
- Wait till configuring ends; the light on the device will be ON. When configuration finishes, the light goes OFF



MAIN SCREEN:

- Tap the microphone icon to open the Audio Recorder screen (recording, SD card access; live listening only on older app versions).
- Tap the Setup icon to enter setup
- Share icon to share access to the device
- + icon to add another device to the same app
- Alarm log to see all voice-activated alarms
- Account to see your account details



LIVELISTENING SCREEN:


On older app versions, you can listen to live audio from the device here (headphones are recommended).

On the latest app version, this function is not available.

Tap on SD card, then choose SD card storage to access your recordings on the SD card

On the recording list, tap on the right icon to download the file.

Once the file is downloaded, you can play it



RECORDING SETTINGS PAGE:

Continuous record mode: In this mode device will always be connected in a WiFi network and will always record. In this mode, battery consumption is maximum

Power-saving mode A: This is standby mode; when sound is present, the device records. WiFi is on standby (not connected but ready to connect at your request). You can connect to the device anytime to download recordings or change settings (and for live listening on older app versions). Battery consumption is moderate. These settings are RECOMMENDED.

Power-saving mode B: This is deep sleep mode with the lowest battery consumption; WiFi is OFF, and the device cannot be reached if there is no sound present.

Voice activation works, and the device is Wi-Fi accessible for downloads and setup changes (and live listening on older app versions) only during the recording interval.

Be careful with this mode, especially if trigger sensitivity is on Low, possible that the device will be always OFF .