

### USER MANUAL: STronic UR125-075




**STronic UR125-075** is very powerful yet very small device. It has a USB MINI port for easy data extraction. The module is equipped with very sensitive microphone which allows you to get really good quality sound with extra long battery life.

Device is very compact and easy to use.

# **STronic UR125-075**



#### FIGURE 2



# **QUICK SET-UP GUIDE:**

#### **IMPORTANT:**

- DEVICE CHARGES WITH CABLE ONLY (faster charging is with enclosed adaptor)
- USE APPROPRIATE OPERATING SYSTEM (Windows XP,7,8,8.1)
- DEVICE IS NOT WATER RESISTANT



When you place the device on the table, with the connector facing up, like on the FIGURE 2, and you push the switch **to the left** you will activate the mode of continuous listening. In the basic module STronic UR125-**075** the second number denotes the amount of hours in this case **75 hours** that the device can record.

POSITION 2
VOICE ACTIVATION

When you place the device on the table, with the connector facing up, like on the FIGURE 2, and you push the switch to the right you will activate the mode of continuous listening. In the basic module STronic **UR125**-075 the first number denotes the amount of days in this case **125 days** that the device can last in standby.

POSITION 3
SWITCHING OFF

When you put this device into Position 3, it will be SWITCHED OFF.

# **TECHNICAL SPECIFICAITON**

**Recording Time:** max capacity 144 hrs

**Battery Life:** 75 Hrs

**Standby Time:** 125 Days in voice activation

Charging Time: 3 hrs

**Size:** 50x 21 x 10 mm

Weight: 27.2g

# **PACKAGE CONTENT**

- 1. STronic UR125-075
- 2. Charger
- 3. USB MINI cable

### **USEFUL INFORMATION**

If battery is fully discharged, charging will start 3 min after connecting the device into power supply.

We recommend to format battery before you start using the device. Charge the device at least 10 hours and then let it discharged. Repeat three times. After device will be fully formatted, charge it for 8 hours, ideally.

Please note, quality of mobile signal in the place of installation strongly affects quality of interception When device is not rechargeable, re-insert SIM card or re-charge the device

When call back function doesn't work properly, even if activated, re-insert SIM card

## **CHARGING**

When unplugged from the cable:

0-30% battery: No falsh or ligh

30-70% battery: One flash

70—100% battery: Light ON

## **DISCLAIMER**

This user manual can be slightly different from specific product.

Before start using the device, check your local legal terms. Neither supplier nor distributor don't assume and responsibility for using device in conflict with local law.

